



APT音声コーデック音声通信互換表 1/2

2009年1月30日

通信が可能です ×通信は出来ません 弊社までお問い合わせ下さい

	DSM100/ProLink	DSM100/ProMusic	DSM100/I-MUX	DSM100/RS449II	DSM100/RS449	NXL384(256)A	NXL384D	BCF384(256)
DSM100/ProLink		*1	*1	×	×		×	*2
DSM100/ProMusic	*1			×	×	×	×	*2
DSM100/I-MUX	*1			×	×	×	×	*2
DSM100/RS449II	×	×	×					*3
DSM100/RS449	×	×	×					*3
NXL384(256)A	×	×	×					*3
NXL384D	×	×	×					*3
BCF384(256)	*2	*2	*2	*3	*3	*3	*3	
at-220SR(N)	×	×	×					*3
WorldNet Rio	×	×	×					*3
WorldNet Rio2(MPEG)	×	×	×					*3
WorldNet Milano				*3	*3	*3		*3
WorldNet Sapporo				*4	*4	*4		*4
WorldNet Tokyo				*3	*3	*3		*3
WorldCast Meridian	×	×	×					*3
WorldCast Eclipse				*4	*4	*4		*4
C100xr	×	×	×					*3
C300xr	×	×	×	*3	*3	*3		*3
C310xr	×	×	×	*3	*3	*3		*3
C400xr	×	×	×	*3	*3	*3		*3
C450xr	×	×	×	*3	*3	*3		*3
C510xr	-	-	-	-	-	-	-	-
C520xr	-	-	-	-	-	-	-	-
C530xr	-	-	-	-	-	-	-	-

	at-220SR(N)	WorldNet Rio	WorldNet Rio2(MPEG)	WorldNet Milano	WorldNet Sapporo	WorldNet Tokyo	WorldCast Meridian	WorldCast Eclipse
DSM100/ProLink	×	×	×				×	
DSM100/ProMusic	×	×	×				×	
DSM100/I-MUX	×	×	×				×	
DSM100/RS449II				*3	*4	*3		*4
DSM100/RS449				*3	*4	*3		*4
NXL384(256)A				*3	*4	*3		*4
NXL384D								
BCF384(256)	*3	*3	*3	*3	*4	*3	*3	*4
at-220SR(N)	*3			*3	*4	*3		*4
WorldNet Rio	*3			*3	*4	*3		*4
WorldNet Rio2(MPEG)	*3			*3	*4	*3		*4
WorldNet Milano	*3	*3	*3				*3	
WorldNet Sapporo	*4	*4	*4				*4	
WorldNet Tokyo	*3	*3	*3				*3	
WorldCast Meridian	*3			*3	*4	*3		*4
WorldCast Eclipse	*4	*4	*4				*4	
C100xr	*3			*3	*4	*3		*4
C300xr	*3	*3	*3	*3	*4	*3	*3	*4
C310xr	*3	*3	*3	*3	*4	*3	*3	*4
C400xr	*3	*3	*3	*3	*4	*3	*3	*4
C450xr	*3	*3	*3	*3	*4	*3	*3	*4
C510xr	-	-	-	-	-	-	-	-
C520xr	-	-	-	-	-	-	-	-
C530xr	-	-	-	-	-	-	-	-

*1 : DSM100の設定が海外仕様 (E仕様) の時のみ通信が可能。

*2 : BCF256 (384) の設定が必要。

*3 : 内蔵TAは使用出来ません。外部TAを用意する必要があります。

*4 : 外部TAを用意する必要があります。

WorldCast Eclipseの対向側のTAがNB-128A/384A,NB-64MD / の場合、内蔵TAで通信が出来ます。



APT音声コーデック音声通信互換表 2/2

2009年1月30日

通信が可能です ×:通信は出来ません :弊社までお問い合わせ下さい

	C100xr	C300xr	C310xr	C400xr	C450xr	C510xr	C520xr	C530xr
DSM100/ProLink	x	x	x	x	x	-	-	-
DSM100/ProMusic	x	x	x	x	x	-	-	-
DSM100/I-MUX	x	x	x	x	x	-	-	-
DSM100/RS449II		*3	*3	*3	*3	-	-	-
DSM100/RS449		*3	*3	*3	*3	-	-	-
NXL384(256)A		*3	*3	*3	*3	-	-	-
NXL384D						-	-	-
BCF384(256)	*3	*3	*3	*3	*3	-	-	-
at-220SR(N)		*3	*3	*3	*3	-	-	-
WorldNet Rio		*3	*3	*3	*3	-	-	-
WorldNet Rio2(MPEG)		*3	*3	*3	*3	-	-	-
WorldNet Milano	*3	*3	*3	*3	*3	-	-	-
WorldNet Sapporo	*4	*4	*4	*4	*4	-	-	-
WorldNet Tokyo	*3	*3	*3	*3	*3	-	-	-
WorldCast Meridian		*3	*3	*3	*3	-	-	-
WorldCast Eclipse	*4	*4	*4	*4	*4	-	-	-
C100xr	*3	*3	*3	*3	*3	-	-	-
C300xr	*3					-	-	-
C310xr	*3					-	-	-
C400xr	*3					-	-	-
C450xr	*3					-	-	-
C510xr	-	-	-	-	-	-	-	-
C520xr	-	-	-	-	-	-	-	-
C530xr	-	-	-	-	-	-	-	-

*1: DSM100の設定が海外仕様(E仕様)の時のみ通信が可能。

*2: BCF256(384)の設定が必要。

*3: 内蔵TAは使用出来ません。外部TAを用意する必要があります。

*4: 外部TAを用意する必要があります。

WorldCast Eclipseの対向側のTAがNB-128A/384A,NB-64MD / の場合、内蔵TAで通信が出来ます。